

# SurfDek

www.surfdek.co.uk

## INSTALLATION GUIDE

Whether you have applied a traction pad before or not, here is our guide to the perfect application.

**Tools required:** knife, tape, acetone or cleaner (non-new board)



1

If your board has had wax or another traction pad on it, please thoroughly remove any left over wax or glue residue. We recommend acetone or a similar wax/glue removal product. We would also recommend putting your pad onto your board in a warm environment (18+ degrees celcius).



3

Gently crack the 3M backing tape so it becomes two sections and makes it easier to peel the edges away. You can also use a hairdryer to gently heat the 3M backing before the next steps.



2

Using a knife, score the reverse of the centre section of your pad along the 3M backing between any cut outs on your design. Cut through the 3M backing only, not into the foam.



4

Using tape, stick down the top and sides of the centre section in place. This will keep the position of your pad whilst you stick down the bottom section.



5

Keeping the top of the centre piece in position with the tape or your hands, peel the bottom section 3M backing away and stick down.




6

With the bottom of the centre section stuck down, remove the opposite end of the tape and stick down.



7

Position on outer pieces of your tail pad.



8

Hold down the kick tail section firmly with one hand. Lift the longer section and peel back the 3M backing. Roll forward and stick down.



9

Lift the kick tail section, peel off the 3M backing and press firmly down. Repeat with the opposite side of the tail pad.