

SurfDek

CREATE A TEMPLATE

Please follow these instructions carefully.

The more precise and clearer your template is, the better the finished product will be.

1. Place the **Mylar templating material** over the entire area to be templated. **Cut the material** to approximately 20mm larger than the area you are going to template. (see #1 on diagram page 3)
2. **Secure the material** in place using masking tape.
3. Draw the area(s) you would like to be covered in traction onto the sheet of Mylar.
4. **At the top and bottom of the templated area, precisely mark with a "X" the centre or stringer line. Do this for each area if the template is in sections - front pad top + bottom, tail pad top + bottom etc (see #2 on diagram page 3)**
5. If you are **choosing to add a logo or text**, write "logo here" or "text here" where it should be in each instance. (see #3 on diagram page 3)
6. **Write your details on the template** including full name, email, mobile number. Add also the board make, board model, your chosen colour(s) and pattern. (see #4 on diagram page 3)
7. **DO NOT CUT** the material to the lines you have templated. We use this extra space in the digitalisation process.
8. **Photograph the traced area before removing the Mylar templating material and email the images to us.**
9. Post the template back to us.

SurfDek

RETURNING YOUR TEMPLATE

Please send photographs of your template in position to contact@surfdek.co.uk

When it is time to send your templates back to us, please complete the attached form and put this in with the template.

Return address:

SurfDek Limited
 South Shields Business Works
 Henry Robson Way
 South Shields
 Tyne and Wear
 NE33 1RF
 United Kingdom

SurfDek

TEMPLATE FORM (PLEASE RETURN)

Full Name	
Address	
Email Address	
Mobile Number	

Board Make	
Board Model	
Colour Choice	
Pattern	
Notes (for example if you would like a kicktail)	

SurfDek

REFERENCE DIAGRAM

